

# **| FS SERIES FLOW SWITCHES**

FLOW DETECTION SWITCHES



These flow switches are designed for use in liquid flow systems at pressures up to 10 bar and temperatures up to 85°C.

The design is based around a moving magnet and a fixed reed switch with a low flow restriction.

The switches are designed to be used in liquids only and should not be used in systems with significant amounts of solid particles.

Custom versions can be made for particular applications.

#### **Features**

- 15mm and 22mm tube versions
- Low flow versions available
- Maximum Operating Pressure 10 bar
- WRAS approved for use in cold and hot water up to 60°C
- Operating temperature rated to 85°C



### **Technical**

| Material                 | Acetal Resin       |       |        |       |        |  |
|--------------------------|--------------------|-------|--------|-------|--------|--|
| Color                    | Black              |       |        |       |        |  |
| Temp. Range °C           | -20 / +85          |       |        |       |        |  |
| °F                       | -4 / +185          |       |        |       |        |  |
|                          |                    | FS15A | FS15LF | FS22A | FS22LF |  |
| Must Operate Flow Rate*  | liters/min         | 2.0   | 0.90   | 3.75  | 1.75   |  |
|                          | US Gal/min         | 0.53  | 0.24   | 0.99  | 0.47   |  |
| Must Release Flow Rate # | liters/min         | 0.3   | 0.25   | 1.40  | 0.75   |  |
|                          | US Gal/min         | 0.08  | 0.07   | 0.37  | 0.20   |  |
| Cable                    | 25cm PVC insulated |       |        |       |        |  |

## Electrical

| Contact Form             |    | N/O with no flow |
|--------------------------|----|------------------|
| Switching Power Max      | VA | 25               |
| Switching Voltage AC Max | V  | 240              |
| Switching Voltage DC Max | V  | 120              |
| Switching Current Max    | A  | 0.6              |

All ratings are resistive load only.





|        | Must Operate I/min | Must Release I/min | Approvals |
|--------|--------------------|--------------------|-----------|
| FS15A  | 2.0                | 0.3                | WRAS      |
| FS15LF | 0.90               | 0.25               | WRAS      |
| FS22A  | 3.75               | 1.40               | WRAS      |
| FS22LF | 1.75               | 0.75               | WRAS      |

<sup>\*</sup> The switch will have operated (contacts closed) when the flow rate rises above this value.

NB Operate and release flow rates only apply when the switch is mounted with the flow direction vertical. The sensitivity of the switch is reduced when mounted with the flow direction horizontal.




Flow switches can be mounted with the flow direction horizontal or vertical (upward flow). The cap with cable connection must always be upwards, as the piston is returned to its released position by gravity. When using metal compression fittings to connect flow switches to copper tube, care must be taken not to over-tighten the fittings onto the flow switch body.

#### **CAUTION!**

The use of plastic plumbing fittings may affect the electrical earth continuity bonding as required by IEE regulations. If in doubt, consult a qualified electrician.



All dimensions are in millimeters.



Made in the UK

Page 2

Datasheets provided by Sensata Technologies, Inc., its subsidiaries and/or affiliates ("Sensata") are solely intended to assist third parties ("Buyers") who are developing systems that incorporate Sensata products (also referred to herein as "components"). Buyer understands and agrees that Buyer remains responsible for using its independent analysis, valuation, and judgment in designing Buyer's systems and products. Sensata datasheets have been created using standard laboratory conditions and engineering practices. Sensata has not conducted any testing other than that specifically described in the published documentation for a particular datasheet. Sensata may make corrections, enhancements, improvements, and other changes to its datasheets or components without notice. Buyers are authorized to use Sensata datasheets with the Sensata component(s) identified in each particular datasheet. HOWEVER, NO OTHER LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE TO ANY OTHER SENSATA INTELLECTUAL PROPERTY RIGHT, IS GRANTED HEREIN. SENSATA DATASHEETS ARE PROVIDED "AS IS". SENSATA MAKES NO WARRANTIES OR REPRESENTATIONS WITH REGARD TO THE DATASHEETS OR USE OF THE DATASHEETS, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING ACCURACY OR COMPLETENESS. SENSATA DISCLAIMS ANY WARRANTY OF TITLE AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, QUIET ENJOYMENT, QUIET POSSESSION, AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHTS WITH REGARD TO SENSATA DATASHEETS OR USE THEREOF.

All products are sold subject to Sensata's terms and conditions of sale supplied at www.sensata.com. SENSATA ASSUMES NO LIABILITY FOR APPLICATIONS ASSISTANCE OR THE DESIGN OF BUYERS' PRODUCTS. BUYER ACKNOWLEDGES AND AGREES THAT IT IS SOLELY RESPONSIBLE FOR COMPLIANCE WITH ALL LEGAL, REGULATORY, AND SAFETY-RELATED REQUIREMENTS CONCERNING ITS PRODUCTS, AND ANY USE OF SENSATA COMPONENTS IN ITS APPLICATIONS, NOTWITHSTANDING ANY APPLICATIONS-RELATED INFORMATION OR SUPPORT THAT MAY BE PROVIDED BY SENSATA.

Mailing Address: Sensata Technologies, Inc., 529 Pleasant Street, Attleboro, MA 02703, USA

# CONTACT US

+44 (0)1202 897969 support@sensata.com Cynergy3 Components Ltd. 7 Cobham Road, Ferndown Industrial Estate, Wimborne, Dorset, BH21 7PE, United Kingdom

<sup>#</sup> The switch will have released (contacts open) when the flow rate falls below this value.